



**NOTES:**

1. Once the membrane system has been installed the existing sleepers may be encapsulated.
2. Remove any loose or flaking materials from the wood sleeper and ensure that there is no residual oils present on the new membrane.
3. Once the area has been properly prepared detail the sleeper with #800 and polyester membrane per detail DP-3CRS.
4. When detailing be sure to extend a minimum of 4" onto the existing membrane.
5. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

*\*This Detail is intended for conceptual purposes only.*



**DETAIL DESCRIPTION:**

**Equipment Sleepers Immovable/Encapsulate**

**ISSUE DATE:**

**12/29/2014**

**DETAIL NUMBER:**

**SD-SUP2**