



NOTES:

1. Once the membrane system has been installed the penetration detailing may be applied.
2. Remove any loose or flaking materials from the pitch pan assembly and ensure that there is no residual oils present on the new membrane.
3. Fill any voids in the pitch pan with a non-shrinking grout or other approved filler. Form a slight cone from the penetration to the outside pan edge to properly shed water.
4. Once the area has been properly prepared and primed where necessary, detail the drain with #800 and polyester membrane per detail DP-3CRS.
5. When detailing be sure to extend material onto the penetration flange and extend a minimum of 6" onto the existing membrane.
6. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Pitch Pan Detail

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-PP1