



Scale: NONE

NOTES:

1. Once the membrane system has been installed proper termination must be completed.
2. Apply #800 centered over the membrane termination extended behind the counter flashing and 2" down the membrane to seal the termination. The width of the detailing behind the counter flashing will vary depending on conditions in the field.
3. The counter flashing to wall transition is detailed with #800 and polyester membrane per detail DP-3CRS. Ensure that the detail work extends a minimum of 2" onto either substrate. The polyester width may vary based on the existing condition.
4. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

System Termination @ Wall

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-BCF1