



NOTES:

1. Following the installation of the new Western Colloid Membrane replace any rotted or deteriorating pipe or conduit supports.
2. The supported element must be properly fastened to the new blocking.
3. Cut new modified bitumen membrane to size ensuring that the membrane extends a minimum of 2" on either side of the new support foot print.
4. Encapsulate the slip sheet membrane and new blocking for extended life of the assembly and best aesthetic results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Wood Block Supports

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-SUP3