



NOTES:

1. Prior to the installation of the new Western Colloid Membrane replace any rotted or deteriorating equipment sleepers.
2. Cut new modified bitumen membrane to size ensuring that the membrane extends a minimum of 6" on either side of the new sleeper foot print.
3. Install the new Western Colloid membrane in the field of the roof and extend onto the new modified bitumen membrane slip sheet.
4. Terminate the new membrane with an application of #800 centered over the transition and extending a minimum of 1" to either side.
5. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Equipment Sleepers-New/Removable

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-SUP1