



Scale: NONE

NOTES:

1. Remove any loose or flaking materials from the scupper assembly and the existing membrane.
2. Once the area has been properly prepared and primed where necessary, detail the scupper with #800 and polyester membrane per detail DP-5CRS.
3. When detailing be sure to extend material into the scupper opening beyond the existing materials and extend a minimum of 6" onto the existing membrane.
4. Ensure that the #800 is feathered out at the perimeters if the application to avoid any damming of positive water flow.
5. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Scupper Maintenance

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

RM-S1